


ROXANA DS






BOK LEWY

BOK PRAWY


1




2







5










3



4





AKCESORIA

K 18X 	G 30X 	R 1 KPL 250mm 	O 4X 
S 2X 	J 10X 4x16 	Y 2X 	M 12X 
L 6X 	T 12X 	U 2X 	