







INSTRUKCJA MONTAŻU


LCD




1




2




3




4




5




6














7



8



AKCESORIA

G 30X	K 16X	U 2X	O 4X	NP. 6X
		 128mm		
JJ 12X	Z 4X	S 4X	M 8X	T 8X
 4X25	 PROSTY			
J 8X				
 4X16				