




# INSTRUKCJA MONTAŻU

TV 2S2W




1






2




3




4





5






6



7




8













9


10




AKCESORIA

G 50X 	R 2 KPL 400mm 	U 2X 224mm 	T 20X 
L 16X 4x13 	J 16X 4x16 	S 4X 	M 20X 
K 30X 	N 4X 		


1



2



3



4

